



### Tools Required:

- T30 Torx bit socket & socket wrench
- 5/32" allen wrench
- 7/16" wrench or socket

### Installation Steps

1. Using 5/32" allen wrench and 7/16 wrench attach cup holder to TJ Mounting Bracket (TJMB) with provided button hex screws (2), 1/4" washers (4), and 1/4" locknuts (2). Note orientation of TJMB for drivers or passenger side placement.
2. Remove both upper factory dash bolts located in door jam with T30 Torx bit.
3. Align TJMB and cup holder sub-assembly over factory dash bolt locations and secure with factory bolts.
4. Repeat steps on other side.

Note: If cup holder is too close to dash adjust vertical position of cup holder in upper slotted holes of TJMB.

***TJ Jeep Wrangler Cup Holder Installation Instructions***